Connect to your Computer



Please find video output port on your PC. You can choose the D-SUB.

D-SUB

Step 1: Identify the connector on your PC.



Step 2 for EQ4088P & 4288P: Connect video/ audio signal with appropriate connector cable.



Required Cable Types for Connection

HD15

Mini-Pin Audio

Connect to your Antenna

Step 1: Find your antenna connector.



Step 2 for EQ4088P & 4288P: Connect the antenna to your Auria LCD TV with 75 ohm coaxial cable.



- If you are using cable without CATV converter box, you can connect cable to your Auria LCD TV directly.
- If you are using 300 ohm twin-lead (flat) cable, you will need 300/75 ohm adapter to connect the antenna with your Auria LCD TV.
- If you are using VHF/UHF antenna, you will need a multiplexer.

Required Cable Types for Connection

Coaxial cable
(commercially available)

Notes on Connection

- To enjoy an HD experience, please connect an HD source to this TV.
- When receiving high-definition content signal by over-the-air antenna, it is best to use the HD antenna.
- When using a DVI-to-HDMI cable, please make sure to connect the DVI side first.

auria

Quick Start Guide

Models: EQ4088P, EQ4288P

For Your Convenience

Write down your product serial number. _ _ _ _ _ _ _ _
If you need any assistance, it will help you.
Please contact Auria service team directly if you have questions on the use of your television.

Contact Auria Service Team at: www.Auria.tv
Or call our service team: (877) 375-1065
For repairs call: (626) 839-6667

Please Do Not Return this Product to the Store

For further information, please refer to the User Manual supplied with the TV.
Please keep this Quick Start Guide for your future reference.

1 LCD TV - The Door to High Definition

Welcome to high definition entertainment. Auria LCD TVs bring you a whole new “Full HD Experience”.
Before you start using your new Auria LCD TV, please read this Quick Setup Guide. This guide will explain how to get great performance from your new high definition TV.

Step 1: Register online at: http://www.Auria.com/support
Step 2: Check your accessory contents in packaging.
Step 3: Install 2 AA batteries (included in package) in your remote control.
Step 4: Install your TV.Please refer to the User Guide for detailed instructions.

Enjoy Full HD Experience:

Set up your Auria LCD TV by using proper connections to an HD content source such as your HD cable or satellite box.
This TV is optimized for HDTV.
Please enjoy HDTV with HD programming.

Sources	Comments & Quality
HD Over-the-air Antenna (ATSC) HD Cable Subscription/Programming HD Satellite Subscription HD/Blue-ray DVD Player	High Definition Content Aspect ratio 16:9 Best picture quality ★★★★★
Over-the-air Antenna (ATSC) Cable Subscription/Programming Satellite Subscription DVD Player	Digital Content Aspect Ratio base on program Good picture quality ★★★★
Over-the-air Antenna (NTSC) Cable Programming	Analog Content Original TV aspect ratio 4:3 Normal picture quality

2 Connect your TV with other external devices

Before you start to connect your Auria LCD TV

- Turn off and unplug all components before making connections.
- Power off your TV until you complete all the connections.

	Input	Video Connector	Audio Connector	Supported Resolutions
BEST	HDMI	HD	No need for this input	1080p, 1080i, 720p, 480p, 480i, PC timing (Both HD and SD content)
BETTER	Component	HD		1080i, 720p, 480p 480i (Both HD and SD content)
	S-Video			480i (SD content only)
GOOD	AV			

About the HDMI

HDMI (High-Definition Multimedia Interface) is the standard for HDTV.
It is built to properly handle high bandwidth, uncompressed video and multi-channel audio – All in One Connection.

Connect your PC to your Auria LCD TV

- For the D-Sub connection, you need to apply D-Sub cable and mini 3.5mm audio cable.
- For the DVI connection, you must apply DVI-to-HDMI cable and additional audio cable.
- Change the PC setting to display on TV.
- For detailed information, please refer to your User Manual.
- Please contact Auria Service Team if you had any problem on connection.

Copyright © 2011 EQD Corporation. All right reserved.

Size: A2 (594x420mm) Print Color: CMYK (4 Color)

3 Initial Setup for terrestrial broadcast

Perform the following steps before you press POWER on the remote control unit.
1. Insert the batteries into the remote control unit.
2. Accomplish the connection with your home entertainment and connect the antenna cable to the TV.
3. Plug the AC power cord to the AC outlet.

Step 1: Power on your Auria LCD TV



Step 2: Press MENU to enter the OSD Menu



Step 3: Language setting on the OSD menu:

1. Press ◄/► to OPTION menu and then press ENTER to enter the setting.
2. Press ◄/► to select the desired language listed on the screen.

Step 4: Decide your antenna setting and channel scan on the OSD menu:

1. Press ◄/► to CHANNEL menu and then press ENTER to enter the setting.
2. Press ◄/► to select "Air" or "Cable".
3. Press ▲/▼ switch to Auto Scan and then press ► to enter Auto Scan function.

Step 5: Simple button operations for changing Channels

1. Method 1
   Using ▼ CH ▲ on the remote control or TV.
2. Method 2
   Using remote control buttons 0-9, - to select channel for NTSC/ATSC/CATV.
   To select 1, 2 or 3-digit channel number (e.g., Channel 110):
   Press 1 → 1 → 0
   To select 4-digit channel number (e.g., Channel 23-1):
   Press 2 → 3 → - → 1



Step 6: Simple button operations for changing Volume

1. Changing the volume
   Using – Vol + on the remote control or TV.
   - To increase the volume, press VOL +.
   - To decrease the volume, press VOL -.
2. Mute the current sound output.
   Press MUTE will be displayed on the screen and sound is silenced.



- To exit the OSD Menu after you done the setting, please press "Menu".
- For other detail setting, please refer the User Manual.
- If you watch TV with STB or Satellite box, please switch the INPUT to appropriate input source, and refer the user manual from your service provider for the correct display setting.
- If you have questions on the setting for your Auria LCD TV, please contact Auria Service Team.

4 Watching Your TV

Select your TV source

Select the correct input for your video source using your remote control:
- Press SOURCE repeatedly until you select the correct input.
- For additional operation details refer to your User Manual.
- Please refer to the user manuals for your components for correct output setting.

Adjust Aspect Ratio

Your Auria LCD TV can support different aspect ratios.
HD signals usually have a widescreen aspect ratio of 16: 9 , and SD signals are usually 4:3 aspect ratio. The 16: 9 aspect ratio looks perfect on your Auria LCD TV.
For different aspect ratio, you can:
- Press ASPECT repeatedly on your remote control to change the aspect ratio setting for your need.
- For additional operation details refer to your User Manual.

Customize Picture Mode

Auria LCD TV includes several different modes for the using on different contents.
Press Menu on your remote control and select Picture Mode.
Choose the appropriate mode for your content.
For details, please refer Auria LCD TV User Guide.



Full:
Suitable for stretching 4:3 programs to fill the screen.



4:3:
Suitable for viewing conventional 4:3 programs in their normal format.



Movie Scale:
This mode is useful for 1.78:1 DVDs. When viewing 1.85:1 DVDs movie scale mode will still show very thin black bands at the top and bottom of the screen.



Zoom In:
Suitable for viewing wide-screen 2.35:1 anamorphic DVDs in full screen.

NOTE:

- If lines appears obviously while playing xbox game,turn down the sharpness in the mune, and the Noise Reduction and MPEG Noise Reduction off .
- Improve the pic quality by swicthing the mode between 16：9 and 4：3

Connect to your Home Entertainment Devices

Caution:
- To protect equipment, always turn off the TV before connecting any external equipment.
- Please read the relevant operation manual (Blu-ray disc player, etc.) carefully before making connections.

Please select correct TV source.

HD Connection for your HD Devices, such as HD/Blu-ray DVD player

Step 1: Identify the connector on your STB, DVD Player, …

Step 2 for EQ4088P & 4288P Connect video/audio signal with appropriate connector cable.

Step 1: Identify the connector on your STB, DVD Player, ...



Step 2 for EQ4088P & 4288P Connect video/audio signal with appropriate connector cable.



- If your connecting equipment has only DVI output instead of the HDMI output, you must use DVI-to-HDMI cable for the video and also connect the audio cable for sound.
- This TV is optimized for HDTV. To enjoy HDTV, add an HD video source.
- Please contact Auria Service team directly if you have any questions on the HD connection.

Basic Connection for your SD Devices, such as VCD/DVD player

Step 1: Identify the connector on your STB, DVD Player, ...



Step 2 for EQ4088P & 4288P Connect video/audio signal with appropriate connector cable.



Basic Connection for your SD Devices, such as VCD/DVD player

Step 1: Identify the connector on your STB, DVD Player, ...

Step 2 for EQ4088P & 4288P Connect video/audio signal with appropriate connector cable.



- Please contact Auria Service team directly if you have any questions on the SD connection.

Required Cable types for Connection



Back Panel Connections

EQ4088P & 4288P

NOTE: For STB or recording devices which need the antenna connection. Please connect a second antenna cable from that device to your TV.

Size: A2 (594x420mm) Print Color: CMYK (4 Color)